

**AIVE Smart feeder**

**Install manual**



**AIVE2.0**

**AIVE3.0**

## Copyright notice

All the contents herein is the property of AIM, and must not be reproduced in entire or in part without permission of AIM. The information herein is subject to change without notification and should not be regarded as a commitment by AIM. The documentation is reviewed and revised on a regular basis.

AIM doesn't take responsibility for any errors or omissions in the documentation. Critical evaluation of the documentation by the user is welcomed.

Your comments help us to prepare the future documentation. Please send your comments to: [houns9@aim-fa.com](mailto:houns9@aim-fa.com)

Copyright® by AIM all rights reserved.  
AIVE® is an AIM patented device.  
Created in South Korea

# Table of Contents

<b>1. INTRODUCTION</b>	<b>5</b>
1.1 Basic system configuration of Using AIVE and ROBOT	5
1.2. Main features of AIVE	5
1.3 What to do in an emergency situation	6
1.4 Introduction to AIVE	6
1.5 the inspection sheet of AIVE	9
1.6 the wiring information of AIVE	13
<b>2. COMPONENTS</b>	<b>14</b>
2.1 All the contents of AIVE	14
2.2 Assembled frame status	15
2.3 Control port	17
2.4 Basket design	21
2.5 Shape	21
<b>3. INSTALLATION</b>	<b>22</b>
3.1 Installation	22
3.2 DC	22
<b>4. OPERATION/ How to Use AIVE Program</b>	<b>24</b>
4.1 how to use AIVE program	24
4.2 Digital Input and Output example	25

4.3 TCP/IP (ex. Delta robot, Epson Robot).....	26
4.3.1 Delta robot Example.....	28
4.3.2 EPSON Robot Example.....	29
4.4 programming via digital I/O (ex. Melsoft GX work3 plc).....	30
4.5 I/P Settings.....	31

## 1. INTRODUCTION

### 1.1 Basic system configuration of Using AIVE and ROBOT




Figure 1-1. Basic system configuration of using AIVE® and ROBOT

### 1.2. Main features of AIVE




Figure 1-2. Main features of AIVE

## 1.3 What to do in an emergency situation


Press any E-stop button (A red push-button on a yellow background/ field) on any robot being used with the feeder, power-down the feeder, and then follow the internal procedures of your company or organization for an emergency situation. If a fire occurs, use CO2 to extinguish the fire.

## 1.4 Introduction to AIVE

The AIVE® feeder is a vibratory feeder, capable of feeding a wide range of loose parts for handling by an industrial robot system with vision. The parts may have various shapes and be made of different materials.

For lubricated, fragile, and/or delicate parts, please contact AIM's technical office.

AIVE® feeders are not suitable for handling liquid products or fine grit.



The AIVE® feeder consists of a square plastic box and various board devices on top of the vibration generator. An optional backlight to illuminate the parts is available.

Most of the AIVE® feeder components are enclosed inside the feeder body. A vibration feeder is exposed at the top of the device, the user-supplied camera is mounted above the feeder,

The plastic top of AIVE® is available in different materials and thicknesses, depending

on the kind of parts being fed, as well as the color required for the product. This is the appearance of the AIVE® feeder. Because the vibrating platform is translucent, the camera can identify the silhouette of the plastic part.

The top of the feeder's frame is a steel frame, surrounding the vibrating platform. It is designed to contain the parts, which can be shaken or spread out by centrifugal force.

## Robotic Flexible parts feeding system



### 1-5 the inspection sheet of AIVE

## Inspection sheet

Serial No : AIVE-120-000 (AIVE-specification-YY/MM/DD)  
Product : AIVE  
Model name: AIVE-0000 (the serial number per AIVE)  
The date of issue: 20220303-1 the confirmation of the person in  
charge/the first product of the date of settlement day

The date of test	: YYYY/ MM/DD	signature
Inspector	: OOO	signature
The final confirmer:	OOO	signature



## The test category and result

### 1) Electric test


Item name	The content of test	SPECIFICATION	The result
power	Normality ON/OFF	1time 100times ON/OFF per 5seconds??	
	The inner BOARD normality ON		
ETHERNET	The basic motion by ETHERNET	Activate 2H through MELSEC Q PLC	
I/O	The basic motion using I/O and PLC	Activate 2H through MELSEC Q PLC	
USB	The activation using USB	Activate 2H through 3MM, 20HZ	
MOTOR	Motions of spreading and gathering using AIVE program	After setting up 3MM, 20HZ, 4H After setting up 0.2MM, 80HZ, 4H	
BACK LIGHT	The motion of BACK LIGHT ON/OFF by EHTERNET	Checking the contrast spreads equally on all the side of feeding through vision program, WiZER (Deviation within +-10)	

## 2) The physical switch/LAMP test


Item name	The content of test	SPECIFICATION	The test result
SERVE ON	LAMP lightning by pushing SERVE ON	Repeat 10 times	
HOME	Home movement by pushing Home button	Repeat 10 times	
FUNC #1	activate after setting up 3MM 20HZ,	Repeat 10 times	
FUNC #2	Activate after setting up 0.2MM 80HZ	Repeat 10 times	
Fault Release	Pushing SERVE ON button after pulling out the power motor cable	Repeat 5 times	
Manual ON	While not pushing this button, activate other manual buttons	Repeat 5 times	
Back Light	Checking the normality of Back light on/off	Repeat 5 times	

## 3) The exterior check operation

The list of test	The reference value	The test result
The appearance	No scratch/breakage	
The hole work	Tightening is positive	
	No omission of hole	
The parts	No omission.	



## 1-6 the wiring information of AIVE



The wiring information

## 2. COMPONENTS

---

### 2-1 All the contents of AIVE



The customer would be given AIVE as the photo above  
width: **340** X length: **300** X height: **360** (the dimension of AIVE box)

There are an **AIVE, input cable, output cable, power cable, USB, leveler** in the **box (as photos below)**, please make sure if there are things missed



**AIVE** appearance



**Input, output cable** are same, we provide two cables

## 2.COPONENTS



**Power cable**



**Levelers** (we provide four levelers)




**USB** (It includes manuals and program)



This is the photo the AIVE box open  
The weight of AIVE, box, Styrofoam, all the components included is **8kg**



This is the photo which  
the first Styrofoam is taken out



(It's attached to AIVE)  
Model name: AIVE 2.0  
Serial number AIVE 2.0 no1  
Input: 24vdc (Max 3A, Min 1A)

Each feeder is made up of the following parts.

- Frame
- Control port
- Vibrator
- PICK-UP ZONE  
Size varies according to specification
- BACK LIGHT(optional)

### 2.2 Assembled frame status




Figure 2-1. AIVE appearance

The AIVE feeder is made of thick steel plate to protect the inside from unnecessary external impact.


### 2.3 Control port

There are communication ports and power ports in the control port, tested and provided by us.



The control port includes MAIN POWER SWITCH, LAN PORT, FUSE BOX, USB PORT, and I/O POWER CABLE PORT.


### The AIVE control port manual




The form and section of AIVE control port



## The section of power connection




1. Power button : you can turn on/off AIVE through this button
2. Power connect : you can provide power through this port
3. USB port                      4. Ethernet port



As next to this photo, you can decide the way of communication through this switch and connect the right port.(USB port or Ethernet port)


5,6 : Input, Output

<i>Input</i>	1	<i>A1</i>
	2	<i>A2</i>
	3	<i>A3</i>
	4	<i>STROBE</i>
	5	<i>SPARE</i>
	6	<i>GND</i>
<i>Output</i>	1	<i>FAULT</i>
	2	<i>READY</i>
	3	<i>BUSY</i>
	4	<i>HOPPER</i>
	5	<i>SPARE</i>
	6	<i>GND</i>



The set-up of input, output is as shown above

## The section of manual buttons



\*You can activate the all manual buttons by pushing **Manual on** button

1. Serve on: When you push this button, the motor is powered on and ready to operate

2. Home: When you push this button, the basket top of the AIVE where you put parts is fixed

Then AIVE is ready to operate

3. Func#1, Func#2: the roles of Func#1, Func#2 are gathering or spread the parts on the basket. The parts are gathered with high frequency of vibration or spread with low frequency of vibration. Users can set-up functions of Func#1, Func#2 as users want


4. Fault release: the red LED button turns on in case the feedback of Serve on or Home or connect doesn't come and in the case motor doesn't operate. You can turn off the red LED button by pushing Fault release button after solving these problems.

5. Back light: the white light comes in the basket of AIVE as photo below when you push this button.



6. Reset: All the memories users set in the control port reset when you push this button.

## The section of LED lights




Every single LED light comes in the case the operation which is same with LED's name performs

- Hopper LED is turned on if hopper operates
- Ethernet LED is turned on if the Ethernet port is connected
- Servo on LED is turned on if the Servo on button's pushed
- Ready LED is turned on if Home button's pushed
- Run LED is turned on if Func#1, Func#2 is operating
- Back light LED is turned on if Back light button's pushed
- Fault LED is turned on if the feedback of Servo on or Home, connect doesn't come or the motor doesn't work. You can turn of this light by pushing Fault release button after solving the problem
- Manual on LED is turned on if Manual on button's pushed.

### 2.4 Basket design





- 120mm x 150mm
- Parts size  
5mm ~ 40mm



- 80mm x 50mm
- Parts size  
0.5mm ~ 5mm

### 2.5 Shape



Cylindrical



Thin parts

### 3. INSTALLATION

---

#### 3.1 Installation

1. Position the feeder, checking that it is level and stable
2. Place 190 x 174mm (Width x Height, mm) tabs
3. Use M6 50mm bolt, and bolt it down to the floor.
4. Place the level gauge, and adjust the height using the parts on the following photo.



5. Align it with the robot as possible

#### 3.2 DC

##### Power supply

The 24 VDC power supply is user-supplied.

**NOTE:** *You must provide your own power supply.* Make sure the power cables and power supply conform to the specifications in the following table.

## DC power specification



**CAUTION:** make sure you select a 24 VDC power supply that meets the specifications in the preceding table. Using an underrated supply can cause system problems and prevent your equipment from operating correctly. See the following table for recommended power supplies.

Power Supply	PNP TYPE
CABLE Korea MISUMI	<b>PRC05P-P-A-12-2</b>
Customer-Supplied Power Supply	24 VDC (-10 % + 5 %) 1 A

## Connector assembly

1. Use the supplied connector to attach the user-supplied 24 VDC power supply to the feeder.
2. If necessary, you can purchase the product in accordance with the above specification from MISUMI in Korea.

## 4. OPERATION/ How to Use AIVE Program

### 4.1 How to use AIVE program



Figure 4-1. AIVE program

### AIVE program operation manual

1. You can choose the way of connect here (Ethernet or USB).
2. This is the IP address of AIVE
3. This is the AIVE port number.
4. You can turn on/off the AIVE's motor here
5. You can fix the basket top of the AIVE here then AIVE is ready to operate
6. You can reset all the memories in the AIVE here
7. You can turn on/off the backlight of AIVE here
- 8,9. You can save and play and also set up the motion of AIVE such as frequency, stroke, duration(sec) here

- AIVE default IP : 192.168.0.30, PORT : 1470

## 4.2 Digital Input and Output example

### PLC example



Figure 4-2. PLC configuration






Figure 4-2. PLC configuration

### 4.3 TCP/IP (ex. Delta robot, Epson Robot)

#### Vibration Platform communication Protocol

Modified date: 2018.12.20

> Rates: 9600, Data: 8, Parity: None, Stop: 0  
> ASCII Value

Command	STX	Mode	DATA	ETX	Description
On	<	C	1	>	Actuator On
Off	<	C	2	>	Actuator Off
HOME	<	C	3	>	Actuator Home Position
Motion SAVE1	<	C	4	>	Save Action 1
Motion SAVE2	<	C	5	>	Save Action 2
Reset	<	C	6	>	Equipment Reset
Travel distance	<	P1	NNN	>	Travel Distance : NN.N mm
Sine Waveform Cycle + operating time	<	P2	NN,NN	>	Waveform Cycle : NN Hz, Time: 0~9.9sec
Home Offset Settings	<	P3	NN	>	Home Offset : NN mm
Lamp On	<	L	1	>	Back LED On
Lamp Off	<	L	0	>	Back LED Off

Figure 4-3. Sample system

> Rates: 9600, Data: 8, Parity: None, Stop: 0  
> ASCII Value

### 4.3.1 Delta robot Example

```
function aive()    // ex Delta Robot
    aive=SocketClass("192.168.1.30",1470)    // Enter current IP address
    aive:Send("<C6>")    // Equipment Reset
    DELAY(0.05)    // Delay time

    aive:Send("<C1>")    // AIVE Power ON
    DELAY(0.05)    // Delay time

    aive:Send("<C3>")    // AIVE Home Location
    print("aive_on")    // Output to monitor AIVE ON
    DELAY(4)    // Delay time

    aive:Send("<P1020>")    // AIVE Vibration travel distance
                                2MM SETTING
    print("2.0mm")
                                // Output to monitor AIVE Vibration travel distance 2MM
    DELAY(1)

    aive:Send("<P220,03>")    // AIVE operation 0.3sec
                                operation with 20HZ
    print("20HZ,0.3sec")
    DELAY(2)    // Delay time

End
```

### 4.3.2 EPSON Robot Example

```

Function AIVE                                     //ex Epson Robot Preset IP
  CloseNet #208                                   // Initialize Preset Ports
  OpenNet #208 As Client                           // Port reopened
  WaitNet #208                                     // Waiting for port reply

  Print #208, "<C1>" 'on                          // Transfer Ready command for
                                                    AIVE operation to Port 208
Input #208, data$                                // Wait for Receive data at Port 208
Print #208, "<C3>" 'home                          // Transfer Move to HOME position
                                                    command to port 208
Input #208, data$                                // Wait for Receive data at Port 208
Wait 0.05

Print #208, "<P1025>" //Travel distance           // Transfer the AIVE setting distance to 2.5 MM to port 208
Input #208, data$                                // Wait for Receive data at Port 208
Wait 0.05

Print #208, "<P220,10>" //start                   // Transfer vibrate 0.1sec in operation with 20Hz command to port 208
Print "20Hz 1sec"                                // Output to monitor Vibrate 1 sec in operation with 20Hz
Wait 1.1                                          // Delay time

CloseNet #208                                     // Initialize port


```

## 4.4 programming via digital I/O (ex. Melsoft GX work3 plc)

INPUT description					
A5	Strobe	Input 24V			Function
SPARE	A4	A3	A2	A1	
0	1	0	0	0	Reset
0	1	0	0	1	Action 1
0	1	0	1	0	Action 2
0	1	0	1	1	Home
0	1	1	0	0	Light On
0	1	1	0	1	Light Off
0	1	1	1	0	SERV O ON
0	1	1	1	1	SERE VO OFF
0	0	x	x	x	-

Out Description			
PORT	Function	Active	
1	Fault	Low	24 V → 0V
2	Ready	Low	24 V → 0V
3	Busy	Low	24 V → 0V
4	Hopper	Low	24V

## 4.2 Digital Input and Output example



Connector	Cable number	Usage	Classification
A	1	Minus Power	Power
B	2	PLUS Power	
C	3	A1	INPUT
D	4	A2	
E	5	A3	
F	6	STROBE	
G	7	GND	
H	8	FAULT	Ouptut
J	9	READY	
K	10	BUSY	
L	11	GND	
M	12	SPARE	SPARE

Figure 4-2. I/O Wiring Practice

## 4.5 I/P Settings

Proceed with the ezManager program  
This program is included in the USB file we provide





Figure 4-5. EZMANAGER Setting

1. Connect the LAN cable to the AIVE and power it on.
2. Change the MAC address as the screenshot below.

00	30	f9	14	7a	01	읽기
----	----	----	----	----	----	----

3. Click 'Search All' to display the searched AIVE.
4. The IP address of the current AIVE is displayed on the product IP address of the network item.
5. Enter the IP address you want to change in the product IP address.
6. Press the Save button at the bottom.
7. Search again and confirm that the IP address has been changed.



Figure 4-5. EZMANAGER setting 2

11. The above picture is the screenshot when the AIVE is searched.
12. Set the serial port items as shown above.

- AIVE default IP : 192.168.0.30, PORT: 1470
- The appropriate set-up of serial port
  - #1: RS-932, #2: 9600, #3: TCP server, #4: 1, #5: 0D 00 00 00

The initial set-up would be same with set-up above, but if it's different with any reason, you have to change into the initial set-up